


LWR-1050 Wi-Fi Audio Receiver

Quick Start Guide



Charge

Remove the protective screen cover and clear plastic battery isolation tab. Fully charge by connecting a micro-USB charger or charge in the optional Docking Station. The status LED will flash green during charging and be solid green at full charge.

Setup

The ListenWIFI Manager software for Windows®, available at www.listenwifi.com/support is required for setup.

1. Launch the Manager software and create an account (or log in).
2. Complete the required steps of the Venue Setup section of the Manager software.
3. Add receivers to the Manager software by plugging them in via USB, or by connecting them via the optional Docking Station.
4. Configure receivers as required using the Profiles editor in the Manager, including channel access control, assigning beacons for triggering, language, and other user preference settings.

Basic Operation

1. Press and hold the Power button to turn receiver on. Turn on/off the display by tapping the Power button.
2. Plug ear speaker, smartphone earbuds, or an inductive neck loop into the headphone jack.
3. Select the desired channel by tapping the left soft button when the display is on. Select the desired language, when available, by tapping the right soft button.
4. Adjust volume by pressing volume up and down buttons.
5. To power down, press and hold power button for 3 seconds. Return the receiver to the charger.

For more information on setting up and operating ListenWIFI, please visit our support website and consult the system manual at www.listenwifi.com/support.