

## ListenTALK Quick Start Guide

- LK-1 Transceiver
- LKR-11 Receiver



## INTRODUCTION

### Thank you for purchasing ListenTALK!

For additional details on use, adjustment, or programming, download the full ListenTALK Operations Manual from [www.listentech.com/support/manuals](http://www.listentech.com/support/manuals). To purchase headsets and other accessories, visit: [www.listentech.com/shop-listen](http://www.listentech.com/shop-listen).

### Charge ListenTALKs

Remove the protective screen cover and clear plastic battery isolation tab. Fully charge by connecting Micro USB to USB charger or charge in the optional Docking Station. Status Indicator will be lit solid when fully charged. Optionally, insert three AAA alkaline batteries into Transceivers equipped with the Alkaline Battery Case.

### Power On

Press and hold *Power Button* to turn on. Press and hold three seconds to turn off. While unit is on, momentarily press *Power Button* to activate status display and Leader soft buttons.



For more information visit  
[www.listentech.com](http://www.listentech.com)

## Create a Group

Create a *Leader* and *Sub-Leaders* (optional) by inserting red *Leader Clips* on LK-1. To create a *Group*, Pair *Leader* with *Participants* and *Sub-Leaders* in the Docking Station or using Near-Field Communications as follows: Press and momentarily hold *Leader's Right Soft Button*. Then, touch *Leader's* back to each *Participant's* and *Sub-Leader's* back. A beep indicates successful pairing. Create multiple, independent ListenTalk Groups by repeating this process, with additional units.

## Connect Headsets

Connect Listen Technologies headsets or use standard smart-phone earphones.

## BASIC OPERATION

Press Volume Up or Volume Down button to control volume.

**Leader (LK-1 only)** – Press *Talk Button* to toggle between Talk and Mute. Press and momentarily hold *Left Soft Button* to select Talkback modes (Off, Leader or Group). *Right Soft Button* initiates pairing.

**Participant** – Press and hold *Talk Button* to speak; release to mute. Soft Buttons have no function. Note: LKR-11 has no Talkback functionality.

## Programming and ListenTALK Software Suite

The ListenTALK Software Suite, available at [www.listentech.com/support/software/](http://www.listentech.com/support/software/), features complete setup, inventory management, group creation and naming. Many options are accessible from the Transceiver/Receiver internal menu. Please refer to the ListenTALK Operations Manual.

## Hearing Safety

This product amplifies audio to a high level which could cause hearing damage. To protect your hearing, turn down the volume before putting on the Ear Speaker or Headset, then adjust to your preference.

## Medical Device Safety

Before using this product with an implantable or other medical device consult with your physician or the device manufacturer. Always confirm you are using this product in accordance with safety guidelines established by your physician or the manufacturer.

## Recycling

Please help us protect the environment by properly disposing of batteries. Take batteries or equipment to any electronic recycling collection point or return them to the factory.

© 2018 Listen Technologies Corporation®  
All Rights Reserved 2018

Visit Listen at [www.listentech.com](http://www.listentech.com)  
or telephone +1.801.233.8992 or  
1.800.330.0891

20180427